## **Concrete Construction: Post-Fabrication General Instructions**

## **Scope Statement**

Complete inspection, witness repairs, give approval, and complete paperwork for finished project.

## **Procedure**

## QC/QA

- 1. Ensure that the members remain undamaged during transportation from the bed to the storage area, and that the members are properly blocked to prevent damage during storage.
- 2. 2. Witness all repairs of surface imperfections. Secure up-front Structures Division approval for all major repairs (i.e., honeycomb, cracking, windows, etc.).
- 3. After the prefab members are complete, check the dimensions and overall quality of the members. If acceptable, place a red UDOT sticker on the member.
- 4. 4. Write a test report, send a copy with the Bill of Lading to the Project Engineer, and route the original through the standard distribution system.